


Figure 6-3 (Sheet 6 of 11) Main Landing Gear - Wear Tolerances