



Normally the turbine will need to be mounted right at the front of the engine mounting rails, against F5, so that the back edge of the outer casing (the 'chromed' part on Jetcats') is about 15 - 18mm in front of the front edge of the carbon bellmouth and F6 bulkhead.