

$3/32 \times 1/8$ ANTI WARP
(2 REQD)

E-1 (1 REQD)

$3/32$ SHEET BALSA

NOTE:

YOU MAY USE $1/16$ SHT
TO SAVE WEIGHT....

GRAIN
DIRECTION
(TYPICAL)

$3/32$ SHT (2 REQD)
ANTI WARP

- SUGGESTED EQUIPMENT
- ACE R/D TX
- ACE D/E RX
- ADAM LV BABY
- (2) 225 BH NICADS
- GUILLOWS WHEELS &
DECALS

W-6 (2 REQD) $3/32$ SHT

W-5 (2 REQD) $3/32$ SHT

W-4 (2 REQD) $3/32$ SHT

W-3 (2 REQD) $3/32$ SHT

W-2 (2 REQD) $3/32$ SHT

W-1 (2 REQD) $1/4$ SHT

W-10 (10 REQD) $3/32$

W-10A (2 REQD) $1/4$ SHT

$1/16$ DIA WING
SADDLE

• SADDLE BRKT

BRASS

SOLDER

$1/16$ DIA
• LANDING
GEAR WIRE
PATTERN

$1/4$ SHT
(2 REQD)

• SPACER
PLASTIC-PLY

• F-4 (1 REQD) $1/4 \times 1/4$ SPRUCE

W-1

W-2

W-10A

• SAND AS
SHOWN WHEN
ALL DRY...